

large, easy-grip throttle knob with mechanical stop; loco exchange causes throttle knob to find correct position automatically; motor-driven

loco symbol and loco name for easy identification of engine

large tachometer shows present loco speed

large, easy-grip throttle knob with mechanical stop; loco exchange causes throttle knob to find correct position automatically; motor-driven

Loco selection key

function keys with precise click for first 8 loco functions; reliable touch-function without eye-contact

Loco selection key

analog two-way joystick with center click; ideal for analog control functions of loco; just define e.g. length of whistle blow and kind of sound of LokSound V3.5 - prototype-like; also for navigation in menu.

emergency "Stop" button; switches off ECoS center when pushed no longer than 3 seconds

full graphic TFT colour display with touch panel

analog two-way joystick with center click; ideal for analog control functions of loco; just define e.g. length of whistle blow and kind of sound of LokSound V3.5 - prototype-like; also for navigation in menu.

