
TRKL
TRKR
TRKR
MOT+
U+
U+
GND
MOT-
WheelSensor
MOT-
SPK1+
SPK1-
not connected
SPK2+
SPK2-
+10V
+5V
AUX7
AUX8
AUX9
AUX10
Zugbus-Data
Zugbus-Clock
UVAR
RearLight
FrontLight
SENSOR1
AUX1
AUX2
AUX3
SENSOR2
AUX4
AUX5
OFF
AUX6
U+
GND
+5V
SERVO1
GND
+5V
SERVO2
GND
+5V
SERVO3
GND
+5V
SERVO4