ESU Info ECoS 50200

Troubleshooting: Touchscreen without function ex works

Dear new owner of the ECoS 50200,

in some rare cases it could happen that the touch screen of the ECoS delivered ex works is without any function and not responsive to pressure.

Please do not return the ECoS immediately to ESU.

If the touch screen does not respond to pressure, it needs to be re-calibrated. Usually the ECoS comes with a calibrated touch screen ex works. Unfortunately with some of the devices, the calibration hasn't been saved. The following instructions only need to be carried out on the ECoS if the touch screen doesn't react.

Please go ahead with the calibration as follows:

• Push the function buttons F2 and F7 of the left AND the right throttle <u>at the same time</u> for a few seconds



- Now the calibration screen appears.
- Please follow the instructions shown on the screen: Please push the occuring red and green crosses one after another by using the attached stylus. Please try to hit the crosses as exactly as possible.



• Now the message "Calibration finished" appears on the screen. The calibration will be saved when you push the OK button. Now the touch screen works as it should. If the message "Calibraton could not be carried out" occurs, the crosses haven't been hit precisely. In this case please repeat the procedure.

Kalibrierung fertig		
Die Kalibrierung ist erfolgre verlassen.	ich abgeschlossen. Sie können	das Menu nun

We would sincerely like to apologise for the inconvenience caused!

Kind regards ESU Team

